



- | | |
|------------------------------|---|
| S 1 : Main switch** | TS : Timer's microswitch |
| S 2 : Start switch | TH : Thermostat |
| S 3 : Door's cut off switch | TF : Thermofuse |
| M 1 : Wash pump motor | R1 : Boiler's/Booster's heating element |
| M 2 : Timer's motor | R2 : Tank's heating element |
| M 3 : Detergent pump motor * | K : Relay |
| PS : Pressure switch | H : Indicator lamp |
| | Y : Water inlet valve |

**ELECTRICAL DIAGRAM
KNOSSOS 50**

380-400 Volt 3~ AC 50/60 Hz
Max 6600 W 9.6 A/ph