




- | | |
|--|------------------------------|
| S 1 : Main switch | M 1 : Wash pump motor |
| S 2 : Start switch | M 2 : Timers motor |
| S 3 : Doors cut off switch | M 3 : Detergent pump motor * |
| PS : Pressure switch | TF : Thermofuse |
| R 1 : Boiler's/Booster's heating element | TH : Thermostat |
| R 2 : Tanks heating element | TS : Timers microswitch |
| H : Indicator lamp | K : Relay |
| Y : Water inlet valve | |

* OPTIONAL

ELECTRICAL DIAGRAM

MODEL 35

220-240 Volt AC 50/60 Hz

Max 2600 W 12.1 A