




ELECTRICAL DIAGRAM

Model 600

220-240 Volt AC 50 Hz

EMF : Electromagnetic filter
 DS : Door switch
 PS1 : Break tank/boiler pressostat
 PS2 : Tank pressostat
 TP1 : Boiler's thermo probe
 TP2 : Tank's thermo probe
 DTM : Detergent pump motor
 RAM : Rinse aid pump motor
 R1 : Booster's heating element
 R2 : Tank's heating element

TF1 : Boiler's Thermofuse
 TF2 : Tank's Thermofuse
 INV : Inlet valve
 HRV : Hot rinse valve
 CRV : Cold rinse valve
 WPM : Wash pump motor
 RPM : Rinse pump motor
 DPM : Drain pump motor
 DRV : Drain valve
 UI : Users interface