



- | | |
|-------------------------------------|--------------------------------------|
| EMF : Electromagnetic Filter | IV : Inlet Valve * |
| UI : Users Interface | HRV : Hot Rinse Valve |
| DS : Door Switch | CRV : Cold Rinse Valve |
| PST : Pressure Switch Tank | PPM : Pressure Pump Motor * |
| PSBT : Pressure Switch Break Tank * | DPM : Draining Pump Motor |
| TPB : Thermo Probe Boiler | BHE : Boiler/Booster Heating Element |
| TPT : Thermo Probe Tank | THE : Tank Heating Element |
| DTM : Detergent Pump Motor | WPM : Washing Pump Motor |
| RAM : Rinse Aid Pump Motor | C : Capacitor |
| K : Microrelay | |
| TFB : Thermofuse Boiler | |
| TFT : Thermofuse Tank | |
| STF : Safety Thermofuses | |

* OPTIONAL

MODEL 500

220-240 V 1 ~ N 50/60 Hz
 Max Watt 3600 W
 Max Amps 15.9 A

Single-Phase edition of MODEL 500 with all optional operations in function.

When the appliance has not the Break Tank function then there is not the "Inlet Valve", the "Pressure Pump Motor" and the "Pressostat of Break Tank". The HRV and CRV is a Double Inlet Valve that drives the water with the normal pressure of connection into the hydraulic circuit. In this case exist placed an air gap for protection from any trapped air.