



- | | |
|---------------------------------------|--------------------------------------|
| EMF : Electromagnetic Filter | IV : Inlet Valve * |
| UI : Users Interface | HRV : Hot Rinse Valve |
| DS : Door Switch | CRV : Cold Rinse Valve |
| PST : Pressure Switch | PPM : Pressure Pump Motor * |
| PSBT : Pressure Switch (Break Tank) * | DPM : Draining Pump Motor |
| TPB : Thermo Probe Boiler | BHE : Boiler/Booster Heating Element |
| TPT : Thermo Probe Tank | THE : Tank Heating Element |
| DTM : Detergent Pump Motor | WPM : Washing Pump Motor |
| RAM : Rinse Aid Pump Motor | C : Capacitor |
| K1/K2 : Magnetic Contactor | |

K3 : Microrelay

TFB : Thermofuse Boiler

TFT : Thermofuse Tank

STF : Safety Thermofuse

* OPTIONAL

MODEL 500

380-415 V 3 ~ N 50/60 Hz

Max Watt 6600 W

Max Amps 12.2 A

Three-Phase edition of MODEL 500 with all optional operations in function.

When the appliance has not the Break Tank function then there is not the "Inlet Valve", the "Pressure Pump Motor" and the "Pressostat of Break Tank". The HRV and CRV is a Double Inlet Valve that drives the water with the normal pressure of connection into the hydraulic circuit. In this case exist placed an air gap for protection from any trapped air.